


# How to Setup Camera Side Motion Detection when using the Hikvision Smart Driver

In Ocularis 5 when adding a Hikvision device with the Hikvision Smart Driver, the enabling and setting of the motion detection is slightly different then when using a specific Hikvision device driver.

Please also refer to the document 'Setting up Motion Detection on a Hikvision Device' on how to set up motion detection on the camera.



Log into Ocularis Recorder Manager and select the camera that will have motion detection enabled. (1)

Under 'Camera side operation' select 'Event Trigger'. (2)

Select the 'VMD' check box to enable motion detection. You can edit the name and the dead time if desired. (3)

Click 'Save' to save and close the camera configuration page. (4)

Please refer to the 'How to Enable Record On Motion in Ocularis Recorder' to have Ocularis record when the camera side motion event is triggered.